

7ft Turbo Twister Slide Assembly Manual

7ft Tornado Tube Slide Assembly Manual

Tools Needed for Assembly

- Socket Set with 1/2"Sockets
- 1/2"Wrench
- Socket Adapter
- Impact Driver

Parts



(1) Entry Tubewith Cover Plate



(1) Tube Slide Exit



(4) 90 Degree Elbows



Elbows have (4) Top Halves and (4) Bottom Halves.

Hardware



5/16"x1" Bolts



3/8'Washers




5/16"Lock Nuts



5/16"x1 1/2"Lags

Quick Reference Guide



Assembly Process




Step 1.

Turn the Entry Tube so that it angles to the right side of opening. Center the Entry Tube in the opening and make sure bottom of the Entry Tube hole is flush with the deck. Secure Entry Tube with (12) lags with washers around outside perimeter of cover plate.



Step 2.


Assemble four elbows. Insert (12) bolts with washers through holes on overlap side of joining flanges. Secure bolts with (12) washers and locknuts then tighten with tools. Make sure overlaps and flanges are at same ends on both halves before assembly.



Step 3.


Position flange end of the Elbow against overlap end of the Entry Tube. Turn the Elbow to the left so that the joining flanges are horizontal. Then turn the Elbow one bolt hole counterclockwise. Secure Elbow section to Entry Tube with (12) bolts, (24) washers, and (12) locknuts. Start locknuts on bolt threads and then tighten with tools.

Assembly Process




Step 4.

Position the second Elbow flange end against the first Elbow overlap end so the large joining flanges line up. Turn the second elbow counterclockwise one bolt hole and then secure with (12) bolts, (24) washers, and (12) locknuts.



Step 5.

Position the third Elbow with flange end against the second Elbow overlap end so the large joining flanges line up. Turn the third Elbow counterclockwise two bolt holes and then secure with (12) bolts, (24) washers, and (12) locknuts.



Step 6.

Position the fourth Elbow with flange end against the third Elbow overlap end so the large joining flanges line up. Turn fourth elbow counterclockwise two bolt holes and then secure with (12) bolts, (24) washers, and (12) locknuts.


Assembly Process



Step 7.

Install the Tube Slide Exit section against the trimmed overlap end of the fourth Elbow. Loosen the bottom bolts of the Elbow on either side of joining flanges for better hole alignment.

Install the Tube Slide exit against fourth Elbow Flange so that the sides of the Tube Slide Exit are level and there are two holes between the small rib joining flange of the elbow and the top center of the exit.




Step 8.

Secure the overlap end of the last Elbow Tube to the Tube Slide Exit with (2) 5/16"boltswithwashers.

Fasten two bolts into the pressed nuts near the bottom of the Exit making sure the exit is level on both sides.

Install 5/16"x11/2"lagswith washers through the remaining ten holes in the Elbow Flange into the plastic of the Exit Section, taking care not to overtighten the lags in the plastic.



Step 9.

Check to make sure all bolts and lags are secured tightly on the tube slide. Do not overtighten locknuts and lags.

Safety Information



Proper installation and safety is the responsibility of the installer.